

DELUXE LIGHTWEIGHT STROLLER





Scan for instructional video



Escanee para obtener instrucciones en español

Model # ZU002 S153 09/2022

IMPORTANT - READ CAREFULLY AND KEEP FOR FUTURE REFERENCE


△WARNING


Your child's safety depends on you. Proper product use cannot be assured unless you follow these instructions.

How to Keep Your Child Safe While Using this Stroller

- Adult assembly required.
- Never leave the child unattended. Accidents can happen quickly while your back is turned. You must always keep your child in view while your child is in the stroller, even when sleeping.
- Ensure that all locking devices are engaged before use. This prevents injuries caused by stroller collapsing before allowing your child in or near the product.
- Parking brake shall be engaged when placing and removing the children from the product.
- Always set the wheel brakes when stroller is not moving, especially on an incline. This prevents the product from rolling away.
- To avoid injury ensure that the child is kept away when unfolding and folding this product.
- Moving parts on product may create injuries such as finger pinching.
- Do not let the child play with this product.
- To prevent the product from becoming unstable, do not place parcels or accessory items on the canopy, seat, sides of chassis / frame, or over the handle.
- DO NOT put child in storage basket.
- This seat unit is not suitable for children under 6 months.
- This stroller shall be used with one child only.
- Only use this product with children who weigh no more than 50 lb / 22.7 kg.
- Avoid serious injury from falling or sliding out. Always use the restraint system.
- Check that the pram body or seat unit or car seat attachment devices are correctly engaged before use.
- Never use this product on stairways or escalators.
- The product does not replace a cot or a bed. Should your child need to sleep then it should be placed in a suitable pram body, cot or bed.
- This product is not suitable for running or skating.
- Only use accessories and/or replacement parts supplied or recommended by the manufacturer.
- To prevent this product from becoming unstable or tipping, Do not put more than 5 lb / 2.25 kg in storage basket.
- To prevent this product from becoming unstable or tipping, Do not put more than 1 lb / 0.90 kg in the canopy pocket, child seat pocket or cupholder - Hot liquids can burn your child.

PARTS LIST





FRONT WHEELS (2)




REAR WHEELS (2)




CUP HOLDER


OPEN STROLLER










ATTACH FRONT WHEELS







ATTACH REAR WHEELS





ATTACH CANOPY






ATTACH CUP HOLDER


ADJUST SEAT

ADJUST CANOPY







LOCK FRONT WHEEL SWIVEL




OPERATE BRAKES



SECURE CHILD IN SEAT










10-4


ADJUST SHOULDER STRAP HEIGHT



FOLD STROLLER







CARE & MAINTENANCE

- · Clean plastic and metal parts with damp cloth and wipe dry.
- Spot clean fabric with mild soap and water solution.
- If stroller becomes wet, wipe with a soft cloth to prevent rusting on metal frame.
- When storing stroller, never stack other items on top of or in it; this may damage the stroller.
- · Periodically check for worn parts, loose screws, or torn materials and stitching.
- Replace any damaged parts immediately.

Contours® - United States 1100 W Monroe St Chicago, IL 60607

1-888-226-4469 customerservice@contoursbaby.com